

Tilt & Turn Window

The term Tilt before Turn refers to the sequence of operation of the window. These inward opening windows are capable of two modes of operation.

Tilt mode for ventilation

Turn mode for cleaning and emergency exits

OPERATING INSTRUCTIONS

To operate the window, the handle is placed in one of three positions, Closed

Tilt or Turn. The operation sequence commences with the window in the Closed position handle downward.

If a locking handle has been fitted, turn key to unlock

To select Tilt rotate the handle through 90° from vertically downward to horizontal and pull the window inward. The window tilts inward to allow ventilation

To select Turn from the Tilt mode, close the window and rotate the handle from its horizontal position to vertically upwards and pull the windows inward

To select Turn from the Closed position rotate the handle through 180 degrees vertically downward to vertically upwards and pull the window inward

NOTE: The window must always be fully shut before changing the handle position.

The switch barrier projecting from the locking mechanism, adjacent to the handle, is a safety device which ensures that only one mode, Tilt or Turn, can be selected at anyone time. Avoid pressing the switch barrier as this action could result in the window disengaging from its gear.

NOTE: Do not try to open the window when the handle is between these positions.

